FLOWSTUDIOS

SETUP INSTRUCTIONS

REMOVE MIC STAND COMPONENTS FROM CASE 1 AND ASSEMBLE THE STAND:

- 1. Screw the short threaded pole into the base.
- 2. Attach the boom arm to the stand.
- 3. Attach the microphone using the threaded connector.

Situate the mic stand on your worktable, and adjust the boom arm so the mic is positioned 3-4 inches away from your mouth.

OPEN CASE TWO AND SETUP THE PRIMARY SYSTEM:

- 1. Remove iPhone and stand from case and set aside.
- 2. Connect the red tweed mic cable to the Shure SM7B mic.
- 3. Remove the protective wrap from the pop filter, and slide onto mic.
- 4. Connect the Mix3 unit to a power source*, and turn the unit on.

SETUP THE IPHONE BACKUP:

Secure the iPhone and attached microphone in the tripod clamp, positioned on your table so the microphone is facing you. Note, this can be further away than your primary mic.



PACKING LIST

INCLUDED IN CASE 1:

MixPre 3 field recorder and power supply Cloudlifter gain box Sanitized pop filter for microphone iPhone and connected Shure microphone Desktop tripod with iPhone clamp adaptor iPhone charging cable and USB power brick

INCLUDED IN CASE 2:

Shure SM7B microphone
Mic stand base and boom arm

^{*}If the power cable has become detached in transit, re-attach to USB-C port on the unit.



RECORDING INSTRUCTIONS

PRIMARY SYSTEM

Power up the Mix3 unit (on/off switch is on right side.) Confirm the unit is receiving signal from the mic by monitoring the digital meters on the face of the unit. When ready to record, press the physical record button on the face of the unit. The button will stay illuminated red as you record.

You may stop recording at any time, and resume by pressing the record button again.

iPHONE SYSTEM

Power on the iPhone with the button on upper right (no password required.) Open the Shure Motiv app, then simply press the red record button in center of screen. When finished, hit the stop button, and then save the recording by pressing the checkbox.

IMPORTANT! You do not need to read the entire script before going back to correct a specific portion. If you find yourself wanting to repeat sentences or sections, simply re-read that section until you are satisfied, then resume reading the rest of the script.